

Chainsaw Pruning Guard

Fitting Instructions



- (i) Remove bar from your saw
- (ii) Measure 10.5cm on top of bar and 14cm on bottom of bar as illustrated in the diagram above. (Note: measurements are done with the chain removed)
- (iii) Mark the hole positions for bolting the guard to the bar. Centre punch the holes and drill out using a 8mm drill bit. (Note: Make sure the holes are drilled equal distance from top to bottom of the bar. This will allow you to turn your bar from time to time for more even wear on your bar and provide for the correct positioning of the chain running through the guard).
- (iv) Position and tighten the 2 x bolts, spring washers and nuts supplied. (A normal chainsaw spanner can be used to tighten the bolts using the 13mm socket end of the spanner).